


S001474 Action Nursery Swing
FOR CHILDREN 18-36 months





SAFETY GUIDELINES


Warnings

For Children 18-36 months, 20kg maximum
Only for domestic use. This product has not been designed for commercial use in play centers, nurseries etc.
Suitable for indoor and outdoor use.
Only one child per seat at any one time.
This equipment must be assembled and checked by an adult. Two adults may be required to assemble this product. Adult supervision is required at all times.
Always fasten the harness when the child is seated.
Check all nuts, bolts and fittings for tightness and tighten if required.
Check all coverings for bolts and sharp edges and replace when required.
Check swing seats, chain, ropes and any other means of attachments for evidence of deterioration.
Place the product on level surface at least 2 metres from any structure or obstruction such as a fence, garage, house, wall, overhanging branches, laundry line or electrical wires.
DO NOT install the product over concrete, asphalt or any hard surface.
DO NOT orientate the product directly towards the sun.
Leave all fittings finger tight until assembly is complete, for ease of construction. Then tighten firmly.
Do not allow children to stand on the swing seat.
Do not allow the children to jump or climb off any moving equipment.
Do not twist swing ropes or wrap them over the top bar.
Do not allow loose, hooded or baggy clothes to be worn as children can get trapped and may be unable to free themselves.
Do not allow children to climb on parts of this equipment not intended for this purpose.
Do not allow children to wander into the play area whilst the equipment is in use.
Do not allow child to swing to an angle greater than 60 degrees from the resting position.
Regularly check the item for wear and damage, removing the item from use when necessary until replacement parts are fitted.
Failure to assemble and maintain this item as per instruction may cause injury to the user.
Please keep the instructions in a safe place for future reference.
The minimum clearance between the swing seat and ground level should be 200mm
Please do not overtighten nuts and bolts. Use hand tools only.
Do not use power tools. This can weaken the connection points.
Please contact our customer services department if you have any problems.
If any parts look worn or you find any problems, please contact us (details provided in the warranty page at the back of this manual) for replacements. Do not use the product until the problem has been corrected.
Do not modify this item.


SWING PARTS LIST




STEP 1
Seat Assembly




STEP 2
Frame & Swing Assembly



STEP 3
Frame Assembly



STEP 4
Seat Belt Assembly



WARRANTY INFORMATION

Congratulations on your purchase!

This **Action Nursery Swing** is warranted to be free from defects in material and workmanship under normal use and service conditions for a period of **12 months** from the date of purchase of this article. Evidence of unfair usage or incorrect adjustment by the owner will void this promise.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Conditions of Warranty

All warranty coverage extends only to the original retail purchaser from the date of purchase. Please keep your receipt, tax invoice or other proof of purchase.

This warranty does not extend to any damage to a product caused by abuse, improper or abnormal usage, or repairs not provided by us or our Service Centre. Nor does this warranty extend to products used for commercial or rental purposes. This warranty does not cover ordinary wear, tear and weathering, failure to follow directions, improper installation, improper maintenance or acts of God (such as damage caused by storms, lightning, heavy winds and by snow or ice).

Making A Warranty Claim

In order to make a claim under this warranty please direct your enquiries to our Service Centre. You can contact them on our **Freecall 1800 465 070** number or send mail to them at National Service Centre: 6 Sedgwick Street, Smeaton Grange, NSW 2567 – if mailing please include your contact details.

A service representative will then assist you in the appropriate action to be taken. For efficient processing of your enquiry please have proof of purchase, the date of purchase and the retailer name you purchased the item from, and the brand on the product. Photos of the product, and scans of receipts, may be requested to assist with your claim.

The service centre representative will assess the claim. If:

- 1) **There is a minor fault**, they can offer either a replacement spare part, replacement unit, repair or other suitable remedy;
- 2) **There is a major fault**, they can offer a replacement, repair or suggest you return to the store you purchased it from for a full refund.

Please note – a request for compensation will need documentary evidence of the loss or damage suffered. It will also need to be evidenced that such a loss was a reasonably foreseeable result of a failure to comply with a consumer guarantee under the Australian Consumer Law.

- 3) **The product was damaged through abnormal use**, no refund or repair can be offered.

The sending of replacements, spare parts or the cost of repair carried out will be organized and covered by the Service Centre. If collection of the item is required this will be organized by the Service Centre and at our expense. Do not return any products without authorization as this will be at your expense.

Our sales and service centre has been set up to provide assembly assistance, replacement parts and accessories, and to efficiently handle all warranty related matters. Please note upon receiving your warranty claim our Service Centre will send, via post or email, a repair and refurbished goods or parts notice.

SERVICE CENTRE

Contact details and hours of operation.

Freecall 1800 465 070

9:00am – 4:30pm Monday to Friday (excluding Public Holidays)

9:00am – 3:00pm Saturday

This product is warranted and distributed by Action Sports of 48B Egerton St, Silverwater NSW, 2128. Phone 02 8799 3500